


**PROCEDURE FOR WIRING AREA LIGHTS:**

The Profile Area Light is assembled at the factory. The light cartridge is mounted into the head of the pole and will not need to be removed during installation. Do not remove light cartridge during installation.


The following schematic is to be used to connect the unit to line voltage. It is the responsibility of the installer to make sure that all connections are made in accordance with the NEC and local building codes.

**WARNING!:** LED cartridge and driver are not rated for connection or disconnection while energized. Doing so may damage LEDs and will void the warranty. Disconnect incoming power before making or breaking any electrical connections.


**INSTALLATION AND SERVICE SHOULD ONLY BE PERFORMED BY QUALIFIED PERSONNEL.**




BW402-A-NTW-NFL




BW402-A-NTW-FL




BW402-A-TW-NFL




BW402-A-TW-FL




BW402-B-NTW-NFL



BW402-B-NTW-FL



BW402-B-TW-NFL



BW402-B-TW-FL