



Inline straight



Left miter




Piano key straight



Right miter

Bench options

Included components: bench top ships fully assembled



2X – wall mt support



8X – 3/8-16 x 3/4" socket button hd cap screw



8X – 3/8" washer

Tools Required

- (6) non-corrosive anchors per bench, max $\varnothing 9/16"$ size
- Safety glasses
- Hammer drill with bits
- compressed air for clearing anchor holes of debris




Fig. 1 – recommended install spacing

PROCEDURE FOR INSTALLATION:

1. Prepare wall as required.

Note: Landscape Forms is not responsible for wall installation.

Note: DO NOT DRAG bench across concrete or other rough surfaces. This could damage the powder coat finish.

Note: Dimensions given for anchor hole locations are for reference only. Holes should be located using assembled bench as template.

1. Set bench upside down on protective padding.
2. Set wall mount supports in position. Install 4 screws and washers per support as shown in Fig. 2.
3. Position bench in desired location along wall. Brace bench and mark hole locations.
4. Move bench out of position.
5. Drill holes in wall according to anchor manufacturer's instructions.
6. Clear holes of debris.
7. Set bench in position and install anchors. Provide bracing as needed.




Fig. 2 – Install supports

ASSEMBLE WITH CARE! Pangard II® Polyester Powder coat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powder coated parts on packaging foam or other non-marring surface. Do not place or slide powder coated parts on concrete or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.