


Included components for tables with concrete inserts:



Only units with concrete inserts require some assembly. All units with metal or wood inserts ship fully assembled.

- Hardware included: (4) each per concrete insert: 1/4-20 x 3/4" flange button head socket cap screws and 1/4" metal washers, 1/4" rubber washers, rubber corner gaskets and corner clips.

Tools required:

- Proper safety equipment, if necessary.
- 5/32" hex key for installing inserts

ASSEMBLE WITH CARE! Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on concrete or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.

MELDSTONE INSERT INSTALLATION:

NOTE: Do not fully tighten any hardware until the unit is completely assembled. As hardware is installed, tighten just until snug, then loosen ½ turn. Once all hardware is installed, tighten each cap screw a small amount, in a crisscross pattern, until all screws are equally tight.

Wood and metal inserts ship installed in frame.
Install concrete inserts as shown in Fig. 1. Do not overtighten.




Fig. 1 – Install concrete insert