





OPERATING INSTRUCTIONS

OCEAN MASTER MAX SINGLE AND DUAL CANTILEVER AUTO PISTON LIFT

- ① Remove all packaging from parasol, including inside the parasol.
- ② Pull pin to unlock cam lock handle. Make sure cam lock handle is open per drawing shown.
- ③ Insert cover on to mast. Place parasol on SECURITY STEM.
- ④ Push cam lock handle (per drawing shown) until engaged in the proper gear slot with the cam lock handle in the downward position.

** To rotate parasol: Pull pin to unlock cam lock handle, pull up and turn parasol to desired location. Lock cam lock handle down.*



global headquarters

2900 NW 35th Street
Miami, FL 33142 USA
RevDate 2016-02-25

t 305.634.5116
f 305.634.5119



info@tuuci.com
www.tuuci.com



OPERATING INSTRUCTIONS

OCEAN MASTER MAX SINGLE AND DUAL CANTILEVER AUTO PISTON LIFT

- ⑤ Gently separate EACH RIB INDIVIDUALLY from center hub, approx. 24-36"/60-90Cm. If rib does not move easily, DO NOT force. Inspect product for additional packaging.
- ⑥ Push up Handle to Stopper until the cart is locked per drawing shown.



global headquarters

2900 NW 35th Street
Miami, FL 33142 USA
RevDate 2016-02-25

t 305.634.5116
f 305.634.5119


info@tuuci.com
www.tuuci.com



OPERATING INSTRUCTIONS

OCEAN MASTER MAX SINGLE AND
DUAL CANTILEVER AUTO PISTON LIFT

- ⑦ To close, hold Handle then push down Car Lock and slide Handle down.
Close parasol during wind conditions that exceed manufacturer's specifications.
- ⑧ Close parasol with tie back when not in use.



global headquarters

2900 NW 35th Street
Miami, FL 33142 USA

RevDate 2016-02-25

t 305.634.5116
f 305.634.5119

info@tuuci.com
www.tuuci.com

TUUCI
made in miami