

Included components:

- Bench ships fully assembled. Arms, if specified, are factory installed.

Tools Required for Wall Mount option:

- Safety glasses
- (6) Non-corrosive anchors, maximum $\varnothing 1/2"$ (anchors not included with bench)
- Blanket or other padded material, for protecting powder coat finish
- Bracing or support for holding bench in position while anchoring

ASSEMBLE WITH CARE! Pangard II® Polyester Powder coat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powder coated parts on packaging foam or other non-marring surface. Do not place or slide powder coated parts on concrete or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.

PROCEDURE FOR INSTALLATION:

For WALL MOUNT bench:

1. Locate bench in position using temporary blocking. Verify bench seat is level. See Fig. 1 or Fig. 2 for seat height.
2. Mark hole locations.
3. Move bench and drill holes according to diameter and depth required by anchoring hardware manufacturer. Clear holes of debris.
4. Install anchors.

Wall thickness and anchoring type are the responsibility of the installer. Minimum 4000 psi concrete wall is recommended.




Fig. 1 – BACKLESS WALL MT BENCH




Fig. 2 – BACKED WALL MT BENCH