


Table



Bench

### INSTALLATION:

1. Determine placement of unit.
2. Thread anchors into base of unit.
3. Drill Ø40mm holes in concrete slab. Drill to 180mm depth.
4. Clear holes of debris using wire brush and compressed air.
5. Fill holes with epoxy according to manufacturer's recommendations.
6. Slowly set unit in position.
7. Wipe away excess epoxy before it cures.

Included components: (2) M12 x 140mm stud bolts for anchoring

#### Tools required:

- Crane or forklift to move 3880 lbs.
- Wood supports or straps
- Ø40mm masonry drill
- Chemical anchoring adhesive (Hilti HIT RE 500 or equivalent)
- Compressed air and wire brush




Fig. 1 – Table/bench spacing




Fig. 2 – Crane install – strap locations




Fig. 3 – backless bench hole locations




Fig. 4 – table hole locations