




Embedded

#### Included hardware




1x – path  
light tube



1x – luminaire  
head with  
driver plate




1x – luminaire  
cover



1x – socket



3x – M4 x  
20mm socket  
head cap screw




1x – cover  
plate




4x – M6 x  
16mm socket  
button head  
cap screw



4x – 5/16-18 x  
1" hex hd bolt



4x – M6  
tooth  
lock washer



4x – 5/16  
washer

#### Tools Required

- Safety glasses
- Screwdrivers
- Wiring tools and connectors
- 1/2" wrench or socket
- 3mm and 4mm hex keys

**WARNING!:** LED cartridge and driver are not rated for connection or disconnection while energized. Doing so may damage LEDs and will void the warranty. Disconnect incoming power before making or breaking any electrical connections.

#### LIGHTING LAYOUT RECOMMENDATIONS:

Light pole spacing is the responsibility of others. Refer to the Torres Path Light Product Data Sheet, available on [www.landscapeforms.com](http://www.landscapeforms.com), for light distribution options.

**ASSEMBLE WITH CARE!** Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on concrete or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.




Fig. 1 – Minimum footing recommendation




Fig. 2 – Recommended setback from sidewalk




Fig. 3 – embed socket detail

Landscape Forms is not responsible for site preparation and footings. Footing recommendations are included in these instructions.

#### INSTALLATION PROCEDURE FOR PATH LIGHT:

**NOTE:** The embedded pathlight is designed to be installed in new concrete.

1. Prepare footing as required by local codes, see Fig. 1 and Fig. 2 for recommendations.
2. Set socket in place. Verify that socket is in the correct orientation. See Fig. 3 and Fig. 4. Seal bottom of socket tube around conduit to prevent concrete from entering the socket. Top of socket should be flush with top of concrete. Concrete should be cured before proceeding with steps 3-7.
3. Set pole in socket and attach using hex bolts and washers as shown in Fig. 5. Align arrow on base plate with front location of path light.
4. Install cover plate over pole. See Fig. 6. Ensure nut on cover plate is facing down.
5. Make wiring connections (refer to page 3) between driver plate and line-in supply wiring, see Fig. 7.
6. Secure luminaire and driver plate assembly to pole with (4) M6 screws and lock tooth washers, see Fig. 7.
7. Attach luminaire cover with (3) M4 screws, see Fig. 8.




Fig. 4 – socket in new concrete




Fig. 5 – Install cover plate




Fig. 6 – Install cover plate




Fig. 7 – Install luminaire and driver plate




Fig. 8 – Install luminaire cover

**PROCEDURE FOR WIRING PATH LIGHT:**

The following schematic is to be used to connect the unit to line voltage. It is the responsibility of the installer to make sure that all connections are made in accordance with the NEC and local building codes. Connection hardware not included.

**WARNING!:** LED cartridge and driver are not rated for connection or disconnection while energized. Doing so may damage LEDs and will void the warranty. Disconnect incoming power before making or breaking any electrical connections.

**INSTALLATION AND SERVICE SHOULD ONLY BE PERFORMED BY QUALIFIED PERSONNEL.**




Fig. 9 – Path light wiring schematic